

## E. MAINTENANCE

Plast-O-Matic recommends keeping a spare diaphragm seal available for repairs. Seal life will vary in applications due to cycles, temperatures, pressures, chemicals, and concentration. Based on the application, a periodic inspection and maintenance plan should be established.

### Series GGM Gauge Guards

Diaphragm Part Numbers: PTFE: 1017-T

Viton: 1017-V

EPDM: 1017-EP

Body Materials: PVC, PVDF, Glass-filled Polypropylene

Connection: 1/2" NPT female process

1/4" NPT female gauge

Options: Lower Mount Gauge installed and filled (standard option)

Center Back Mount Gauge installed and filled (alternate)

Removable Housing

Acrylic Gauge Shield

1/2" NPT female gauge connection

### Replacement Gauges

Range	Lower Mount Gauge	Center Back Mount Gauge
-30 - 0" Hg	V30L	N/A
0 - 15 PSI	P015L	P015C
0 - 30	P030L	P030C
0 - 60	P060L	P060C
0 - 100	P100L	P100C
0 - 160	P160L	P160C
0 - 200	P200L	P200C

This O-Ring, #011 is supplied for sealing the Gauge to the Gauge Guard. See figure. Drop into gauge port before filling guard. Factory installed gauges already have the O-ring in place.



# PLAST-O-MATIC

V A L V E S , I N C .

## CHEMICAL GAUGE GUARDS

### Series GGM

### INSTALLATION & MAINTENANCE INSTRUCTIONS

#### A. IMPORTANT – BEFORE INSTALLING

Gauge guards will protect gauges and sensors from contact with chemicals, when properly installed and used within the recommended ranges of pressure, temperature, and chemical compatibility. The ultimate determination of material compatibility is previous successful use in the same application. Call our Technical Support for information about your application.

#### VISUAL IDENTIFICATION OF MATERIAL

BODY MATERIAL	COLOR
“PV” (Geon®) (PVC) (Polyvinylchloride)	Dark Gray
“GPP” (20% Glass-Filled Polypropylene)	Opaque White
“PF” (Kynar®) (PVDF) (Polyvinylidene Fluoride)	Translucent White

Geon is a trademark of The Geon Company

Kynar is a trademark of ELF Atochem

**Caution:** Plastic materials degrade in ultraviolet (UV) light or sunlight.

**Caution:** Gauges filled and installed at Plast-O-Matic are tested to the manufacturer's specified accuracy. Gauge accuracy is generally reduced by the guard, especially for low pressure range gauges.

**Caution:** Do not apply pressure unless a gauge is installed. Release process pressure before removing the gauge from the guard.

#### B. MAXIMUM PRESSURE RATING

Series GGM Gauge Guards are rated for the full pressure range of the gauge supplied **when the gauge is factory installed**. When supplied without a gauge, they are rated for 200 PSI and full vacuum after the gauge is properly installed.

# PLAST-O-MATIC

V A L V E S , I N C .

1384 Pompton Avenue, Cedar Grove, NJ 07009 USA

(973) 256-3000 • Fax: (973) 256-4745 • www.plastomatic.com

1&MGM.doc Rev. 4-Sep-06

### C. FILLING AND GAUGE INSTALLATION

**Fill Liquid** – Factory filled gauges are filled with an FDA approved Mineral Oil. Water can be used for room temperature applications. Guards that have an EPDM diaphragm should be filled with an EPDM compatible liquid such as Glycerine.

**Gauge** – Any threaded gauge, transducer, or pressure switch may be installed, although a user supplied device should be checked for leakage at the O-ring seal before assembly. **Do not use thread sealant or tape on the gauge; the gauge will seal on the O-ring.**

#### FILL AND GAUGE INSTALLATION PROCEDURE, 1/4" NPT GAUGES

1. Install the small O-ring in the guard. Pour fill liquid into the guard to about the middle of the threads.
2. Tilt and tap the guard gently to remove as many bubbles as possible. (A small amount of trapped air is acceptable)
3. Fill the gauge as much as possible. Use a small wire or needle to get the bubbles out. If more complete filling is needed, use the vacuum or pressure fill procedure below.
- 3a. **Vacuum Gauge Fill Procedure** – (gauge must be rated for full vacuum) Connect the gauge at the bottom of a reservoir of fill liquid. Draw a vacuum on the top of the reservoir for about 10 seconds. Look for air bubbles coming out of the valve. Release the vacuum and remove the gauge. For a typical fill station description, contact Technical Support.
- 3b. **Pressure Fill Procedure** – As above, except use 10 to 15 PSI pressure, wait 15 seconds after releasing pressure, repeat several times.
4. Screw in the gauge finger tight. The gauge should compress the O-ring(s) and bottom out on the guard body. Do not over tighten, a torque of 10 to 30 inch pounds (1 to 3 Nm) is adequate. **To align the gauge to face "Forward", tighten the process side.** If leakage occurs, contact factory Technical Support for advice.
5. **Pressure Test** – Apply pressure to the process end of the guard. Check for accurate readings at zero and the maximum gauge pressure.
6. If the readings are not accurate, remove the guard from the process connection, push lightly on the diaphragm with a blunt device, loosen the gauge until the pressure reading goes to zero. Retighten the gauge.
7. Clean off residual fill liquid with alcohol.



### FILL AND GAUGE INSTALLATION PROCEDURE, 1/2" x 1/2" GAUGES

(Follow the procedure for 1/4" gauges, with the following modifications) The upper body is directly under the heads of the screws. Two (2) O-rings and a seal disk is required in Step #1. See exploded view below.

#### D. INSTALLATION – PROCESS SIDE

**Threaded Connections** – A suitable thread sealant (for example, PTFE tape) should be applied to male tapered threads to assure a "leak-tight" seal. The assembly need only be made "hand tight" followed by up to a quarter (1/4) turn with a strap wrench. Do not over tighten or use pipe wrenches on plastic pipe and components.

**Non-Threaded Connections** – For solvent cementing or heat fusion, follow instructions supplied with the cement or fusion equipment, or contact your distributor.

**Caution:** Connections should be made only to plastic fittings; metal pipe should only be installed with an intervening plastic nipple. Metal pipe and straight threaded pipe tend to cut, stretch, and distort the plastic bodies, which could result in cracking or leaking over time.

